



Tool Crib 5 Software for Windows

If you are using an X-Rite DTP20 Pulse device with your ORIS software and if that device does not include X-Rite's Color Elite software, then you will need to use X-Rite's Tool Crib 5 Windows application, in order to install the DTP20 device driver.

- ❶ Download the Windows installer (ToolCrib_509_Installer.exe) from the CGS web site.
- ❷ Run the installer, making sure that the DTP20 is **not** connected to the computer.
- ❸ After installation, connect the DTP20 to the computer's USB port. When you see the "new hardware found" pop-up, right click it to enter the wizard. Allow Windows to search automatically for the needed components.
- ❹ Once the wizard tells you it was successful, you are ready to start using the X-Rite DTP20 Pulse with your ORIS software application.